
Sony Vaio PCG-4K1L RAM Replacement

Accessing the RAM in this computer is straightforward and requires minimal disassembly. One RAM slot allows up to 1.5 GB of PC2-4200 RAM.

Written By: Derek Nollsch




TOOLS:


- Phillips #00 Screwdriver (1)

PARTS:

- PC2-4200 512 MB RAM Chip (1)


Step 1 — RAM





- Locate the indicated cover on the back of the laptop (cover not shown in picture)
- Unscrew the small screw shown using a #00 Phillips Head Screwdriver, and remove the cover.

Step 2



- Remove the installed RAM by grabbing the end and forcefully removing from the slot shown (RAM not shown in picture)
- Insert new PC2-4200 RAM making sure to line up notch and inserting RAM until you hear an audible 'click'

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 04:25:48 AM.